

CK6



PRODUCT FEATURES

- A completely newly developed continuous sensor field for the entire keyboard surface replaces the previous capacitive single-key PCB on the CK6
- Indication of important keyboard functions (e.g. CapsLock, NumLock, volume, sensitivity, touchpad, KeyLock) via an OLED display
- Completely closed Gorilla® glass surface
- Compact keyboard layout
- Washable and disinfectable; therefore a high level of hygiene and cleanliness
- Additional functions (see page 2) can be called up via an Fn key, such as
 - * Keylock (when cleaning the keyboard)
 - * Individual setting of the volume
 - * Individual setting of the sensitivity
 - * Numpad/touchpad switching
- The combined touch and numpad function enables an extra-large touchpad
- VESA mounting on the rear (200 mm, 2 x M4)
- EN 60601-compliant EMC

SPECIFICATION

GENERAL:	
Number of keys:	98
Housing type:	Desktop housing
Housing material:	PC-ABS
Surface material:	0.8 mm Gorilla® glass
Switch technology:	capacitive sensor field
Protection grade:	IP65 (on the front side)
Interface:	USB
USB compatibility:	complies with USB 2.0
Cable length:	2 m
Operating temperature:	0 °C to +60 °C

Storage temperature:	-40 °C to +65 °C
Dimensions:	405 x 167 x 22.5 mm
Weight:	750 g
System requirements:	Win®, MacOS® and Linux® *
Declarations:	CE, FCC, RoHS, REACH
Warranty:	4 years on the electrical function
TOUCHPAD:	
Function type:	capacitive
Dimensions:	76 x 90 mm

ORDER INFORMATION

Art. No.	Full Product Name	Layout
KR30220	TKR-098-PRO-TOUCH-KGEH-VESA-WHITE-USB-DE	German
KR30221	TKR-098-PRO-TOUCH-KGEH-VESA-WHITE-USB-US/EU	US/EU
KR30223	TKR-098-PRO-TOUCH-KGEH-VESA-WHITE-USB-CH	Swiss
KR30222	TKR-098-PRO-TOUCH-KGEH-VESA-WHITE-USB-FR	French
KR30224	TKR-098-PRO-TOUCH-KGEH-VESA-WHITE-USB-UK	UK
KR33201	TKR-098-PRO-TOUCH-KGEH-VESA-WHITE-USB-CZ	Czech
KR33202	TKR-098-PRO-TOUCH-KGEH-VESA-WHITE-USB-ES	Spanish
KR33203	TKR-098-PRO-TOUCH-KGEH-VESA-WHITE-USB-IT	Italian
KR33204	TKR-098-PRO-TOUCH-KGEH-VESA-WHITE-USB-SKAN	Scandinavian

Other layouts on request.

* If the operating system meets the hardware requirements of USB 2.0 compatibility.

Changes and errors reserved!

SPECIAL CK6 KEY COMBINATIONS

Key combination	Function	Indication in the OLED display
Fn + 1	Touchpad On / Off	 Touchpad On
Fn + F7	Adjust the sensitivity	    Level 0 Level 1 Level 2 Level 3
Fn + F8	Adjust the volume	    Off Level 1 Level 2 Level 3
Fn + Keylock (for appr. 3 sec.)	Lock / unlock the keyboard	  Lock Unlock

CLEANING

During the keyboard is locked the glass surface can be cleaned with common cleaning or disinfecting agents. The chemical resistance of the glass surface may vary depending on the concentration of the solution and the surrounding conditions. We suggest to check the used cleaning or disinfecting agents carefully with regard to their effect on glass surfaces.

INDIVIDUAL MODIFICATIONS

- Add a custom logo (1 - 4 colour)
- New country layout
- New GUI design
- Cable shortening
- Keytable changes (HID standard)

Changes and errors reserved!